



MAPRAIL INSTALLATION INSTRUCTIONS

1. Place the 1 or 2" maprail flush with the top of the board
2. Using a 7/64 bit drill hole in the center of the maprail spacing them out every 18".
3. Then using the countersink bit that was provided countersink the holes.
4. Screw the 1/2" screws that was provided in the holes and slide in the maprail insert.
5. Put the end caps on.
6. Contact vpsales@marsh-ind.com with questions.