



GENERAL WRAPPED EDGE INSTALLATION INSTRUCTIONS:

- MARK SCREW/GROMMET LOCATIONS ON THE SURFACE OF THE BOARD. SCREW LOCATIONS ON THE CORNERS OF THE BOARD SHALL BE 2" AWAY FROM BOTH SIDES. IF THE DISTANCE BETWEEN SCREW LOCATIONS (DIM A & DIM B) IS GREATER THAN 48", THEN ANOTHER SCREW LOCATION MUST BE MARKED EQUAL DISTANCE FROM THE OTHER SCREWS (DIM C). REPEAT THE PROCESS OF ADDING SCREW LOCATIONS AS NEEDED, SO THAT THE DISTANCE BETWEEN ANY 2 SCREWS NEXT TO EACH OTHER IS NOT GREATER THAN 48".
- PLACE THE BOARD ONTO THE WALL IN THE DESIRED LOCATION.
- PLACE THE GROMMET ONTO THE SURFACE OF THE BOARD OVER THE MARKED SCREW HOLE LOCATION. THEN DRILL THE SCREW THROUGH THE GROMMET AND BOARD AND INTO THE WALL BEHIND IT.
- REPEAT THIS PROCESS FOR ALL MARKED SCREW LOCATIONS.

(NOTE): IF DRILLING INTO BLOCK WALL OR ANCHORS ARE REQUIRED, THEN PILOT HOLES WILL NEED TO BE DRILLED THROUGH THE SCREW LOCATIONS AND INTO THE WALL FIRST. ANCHORS CAN THEN BE PLACED, IF NEEDED. THEN CONTINUE TO SCREW THE BOARD TO THE WALL AS DESCRIBED ABOVE.



PROJECT: WRAPPED EDGE INSTALLATION INSTRUCTIONS		JOB #
DATE:	DRAWN BY:	SCALE:
SUBMITTED FOR:		
MANUFACTURED BY: MARSH PO BOX 1000 – NEW PHILADELPHIA, OH 44663-5100 PH: (330) 308-8865 FAX (330) 339-5875		
THIS DRAWING IS PROPRIETARY TO MARSH INDUSTRIES, INC. AND IS FURNISHED SUBJECT TO AN EXPRESSED AGREEMENT NOT TO USE OR DISCLOSE, DIRECTLY OR INDIRECTLY, FOR ANY PURPOSE. THIS LEGEND SHALL BE MARKED UPON ANY REPRODUCTION IN WHOLE OR IN PART HEREOF.		SHEET 1 OF 1